

技術的な説明

(1)P.Cボードの電源仕様 GND-Vcc5V3A以上 GND-(+12V) 束線図参照

(2)モニターへの接続は、国内で販売されている一般的なカラーモニターに接続可能です。

(3)音量の関節はPCボード上のボリュームで行ない、右へ回すと大きくなります。

(4)P.Cボードは精密装置のため、運送時などは取扱い方に 注意して下さい。

遊び方

- 1人もしくは2人(交替)プレイをすることができます。1.攻撃ボタンで敵を倒し、「パワーアップアイテム」をとります。パワーアップアイテムは、ショット・レーザー・ボム・スピード・ボーナスです。
- 2. 攻撃/ 「ワーアップアイテムは、ショット・レーザー・ ボム ですが、セレクトボタンで選び、攻撃ボタ ンで打って下さい。
- 3.マジックをとると攻撃ボタン、セレクトボタン を同時に押し、画面中の敵を全滅させることができます。
- 4. 画面上のコンバスは出口の方向を示します。
- 5.各ステージ、一定時間内にクリアして下さい。



Technical Information

- (1) Required power capacity
 GND-Vcc 5V 3A or more
 GND-(+12) * See the Wiring Diagram.
- (2) Output
 R(red) analog.positive
 G(green) analog.positive
 B(blue) analog.positive
 Sync. H-V complexed, negative.
- (3) Use the volume knob on the PCB to adjust sound level.

Turn the knob clockwise and it becomes louder.

(4) Handle with care.

Play Instruction

Deposit coins and press I or 2 player start button. 2 players can play alternatingly.

- Destroy the enemies with ATTACK button and capture power up items. Power up features are SHOT GUN, LASER, BOMB and SPEED UP.
- Use SELECT button to select the power up feature among SHOT GUN, LASER and BOMB.
- After capturing the special item MAGIC, you can press both buttons at the same time to destroy all the enemies in one go.
- 4. COMPASS shows you the direction of the exit.
- 5. Complete each stage within a time given.

ティップ スイッチ No1 セット

1. コインスイッチ№1セット

1. —	12/1	2 2 110	1 6 21			
SW	1	2	3	4	コイン	プレイ
0	OFF	OFF	OFF	OFF	1	1
	ON				1	2
	OFF	ON			1	3
	ON				1	4
}	OFF	OFF	ON	OFF	1	5
	ON				1	6
	OFF	ON			1	7
	ON				2	1
	OFF	OFF	OFF	ON	2	3
	ON				2	5
	OFF	ON			3	1
	ON				3	2
	OFF	OFF	ON	ON	3	4
	ON				4	1
	OFF	ON			4	3
	ON				フリー	プレイ

2. コインスイッチ№2セット

SW	1	2	3	4	コイン	プレイ
0	OFF	OFF	OFF	OFF	1	1
	ON				1	2
	OFF	ON			1	3
	ON				11	4
	OFF	OFF	ON	· OFF	1	5
	ON				11	6
	OFF .	ON			1	7
	ON				2	1
	0FF	OFF	OFF	ON	2	3
	ON				2	5
	OFF	ON			3	1
	ON				3	2
	OFF	0FF	ON	ON	3	4
	ON				4	1
	OFF	ON			4	3
	ON				無	效

ディップスイッチ No2セット

1. プレイヤー数

SW	1	2	プレイヤー数
	OFF	OFF	2
0	ON		3
	OFF	ON	5
	ON		7

2. テーブルタイプ/アップライトタイプ(ミニアップライトタイプ含む) 切り換え

SW	3	タイプ
0	OFF	テーブルタイプ
	ON	アップライトタイプ、ミニアップライトタイプ

DIP SWITCH No. I SETTINGS

1. COIN SWITCH No.1 SETTINGS

SW	1	2	3	4	COIN	PLAY
0	OFF	OFF	OFF	OFF	1	1
	ON				1	2
	OFF	ON			1	3
	ON				1	4
	OFF	OFF	ON	OFF	1	5
	ON				1	6
	OFF	ON			1	7
	ON				2	1
	OFF	OFF	OFF	ON	2	3
	ON				2	5
	OFF	ON			3	1
	ON				3	2
	OFF	OFF	ON	ON	3	4
	ON				4	1
	OFF	ON			4	3
	ON				FREE	PLAY

2. COIN SWITCH No.2 SETTINGS

2. 00.						
SW	.1	2	3	4	COIN	PLAY
0	OFF	OFF	OFF	OFF	1	1
	ON				1	2
	OFF	ON			1	3
}	ON				1	4
	OFF	OFF	ON	OFF	1	5
	ON				1	6
	OFF	ON			1	7
	ON				2	1
	0FF	OFF	OFF	ON	2	3
	ON				2	5
	OFF	ON			3	1
	ON				3	2
	0FF	OFF	ON	ON	3	4 .
	ON				4	1
	OFF	ON			4	3
	ON				VC	OID

DIP SWITCH No.2 SETTINGS

1. THE NUMBER OF PLAYER'S LIFE

SW	1	2	NUMBER
	OFF	OFF	2
0	ON		3
	OFF	ON	5
	ON		7

2. CHANGE OF TABLE OR UPRIGHT

SW	3	TYPE	
	OFF	TABLE	
0	ON	UPRIGHT	

3. ボーナス設定

J. 71	770	./-	
SW	4	5	ポーナス
0	OFF	OFF	1回目30,000PTS 1回目70,000PTS
	ON		1回目40.000PTS 2回目80.000PTS
	OFF	ON	初回 40,000PTSのみ
	ON		初回 50,000PTSのみ

4 ゲームの難度

4. /				
SW	6	7	難度	
	OFF	OFF	易しい	
0	ON		普通	
	OFF	ON	難しい	
	ON		大変難しい	

5 アモ中の音

0. /	- 1	
SW	8	音
	OFF	無
0	ON	有

ディップスイッチ No3セット

1 レアオスクリーン (モニター) 反転切り換え

SW	1	ビデオスクリーン (モニター)
0	OFF	正常
	ON	反転

2 通常アップライトタイプ/VSアップライトタイプ切り換え

C . ~		
SW	2	タイプ
0	OFF	通常アップライトタイプ(ミニアップライト含む)
	ON	VSアップライト

3. モード切り換え

J		
SW	3	モード
0		ゲームモード
	ON	テストモード

4. コンティニュー限定回数

	-T		
ı	SW	4	回数
		OFF	30
	0	ON	50

〇:は標準設定

マニュアルテスト

(1)起動方法

ディップスイッチM3のSW3をONにして電源を入れることにより、マニュアルテストが行えます。

1プレーヤー側のスタートボタンを押すことにより、チェック項目が移行します。

(2)テスト項目

- 1. 画面歪みの調整
- 2.色調整
- 3.1/0チェック
- 4.コインカウンターチェック
- 5.サウンドチェック
- 6. ディップスイッチ設定

セルフテスト

正常な場合:OKと表示後、ゲームが始まる。 異常な場合:BADと表示され、止まる。

3. BONUS SETTINGS

SW	4	5	BONUS LIFE
0	OFF	OFF	AT 30,000PTS AND EVERY 70,000PTS
	ON		AT 40,000PTS ANO EVERY 80,000PTS
	OFF	ON	AT 40,000PTS AND ONLY
	ON		AT 50,000PTS ANO ONLY

4 DIFFICITY OF GAME

-			- (Mari -) This
SW	6	7 _	DIFFICLTY
0	OFF	OFF	EASY
	ON		NORMAL
	OFF	ON	OIFFICLT
	ON		VERY DIFFICLT

5 SOUND IN ATTRACTIVE MODE

SW	8	SOUND	
	OFF	OFF	
0	ON	· ON	

DIP SWITCH No.3 SETTINGS

1 VIOEO SCREEN FLIP

			_
SW	1	VIOEO SCREEN (MONITOR)	
0	OFF	NORMAL	
	ON'	UPSIDE OOWN	

2 SINGLE/DUAL CONTROL UPRIGHT

SW	2	TYPE
0	OFF	SINGLE UPRIGHT CONTROL
	ON	OUAL UPRIGHT CONTROL

3. CHANGE OF MODE

J. 0.	11102 01 111002		
SW	3	MOOE	
0	OFF	GAME MODE	
	ON	CHECK MODE	

A CONTINUATION

4.00	4. CONTINONTION				
SW	4				
	OFF	UP TO 3 TIMES			
0	ON	UP TO 5 TIMES			

O: Shows recommended settings.

Manual Test

(I) How to start

Turn on the power while the SW of the DIP SWICH No. is on. Push player Istart button to change item.

(2) Test items

- 1. Picture contortion
- 2. Color check
- 3. I/O check
- 4. Coin counter check
- 5. Sound check
- 6. Dip switch settings

Self Test

Normal: OK will be displayed. Then the game will start.

Abnormal: BAD will be displayed and the screen will stop.

